

COBRA

® 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissybar with Pad
- 2 - Left and Right Mounting Brackets
- 2 - 8mm x 35mm; 2 - 8mm x 45 mm Button Head Bolts
- 4 - 8mm x 16mm Button Head Bolts
- 2 - Long Spacers (.670")
- 2 - Short Spacers (.305")

Application(s) >

Kawasaki VN900 06-19

Instruction Manual >

02-4968, 02-5968, 02-5468

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove (2) M8 bolts from left side fender rail/rear fender and discard. Install left sissybar mounting bracket (part number should face inward), by inserting the longer supplied M8 bolt through bracket, supplied longer spacer, stock fender isolator bushing, into front hole of fender rail and into fender, (**DO NOT TIGHTEN.**) Install shorter supplied M8 bolt through rear mounting hole of bracket, shorter spacer, stock fender isolator bushing, rear hole of fender rail and into fender, (**DO NOT TIGHTEN.**) Repeat for right side bracket.
2. Install the sissy bar between brackets using the supplied (4) M8 x 16 mm button head bolts.
3. Align sissybar and tighten all hardware. Torque all bolts to appropriate values.

***Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**



® 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissybar with Pad
- 2 - Left and Right Mounting Brackets
- 2 - 8mm x 35mm; 2 - 8mm x 45 mm Button Head Bolts
- 4 - 8mm x 16mm Button Head Bolts
- 2 - Long Spacers (.670")
- 2 - Short Spacers (.305")

Application(s) >

Kawasaki VN900 06-19

Instruction Manual >

02-4968, 02-5968, 02-5468

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove (2) M8 bolts from left side fender rail/rear fender and discard. Install left sissybar mounting bracket (part number should face inward), by inserting the longer supplied M8 bolt through bracket, supplied longer spacer, stock fender isolator bushing, into front hole of fender rail and into fender, (**DO NOT TIGHTEN.**) Install shorter supplied M8 bolt through rear mounting hole of bracket, shorter spacer, stock fender isolator bushing, rear hole of fender rail and into fender, (**DO NOT TIGHTEN.**) Repeat for right side bracket.
2. Install the sissy bar between brackets using the supplied (4) M8 x 16 mm button head bolts.
3. Align sissybar and tighten all hardware. Torque all bolts to appropriate values.

***Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**