

COBRA

® 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 2 - M10 x 40mm Button Head Bolts
- 2 - M10 x 50mm Button Head Bolts
- 4 - M8 x 20mm Button Head Bolts
- 4 - Washers

Application(s) >

Honda Aero 750 04-09, 2011-2014

Instruction Manual >

02-7618 / 02-8618

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar. Note: Install one side at a time

1. Remove the stock fender rail allen bolts from the fender rail. Install the left side sissy bar bracket with the stamped number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M10x50mm button head bolt thru the bracket, washer and into the fender rail. Insert the M10x40mm button head bolt thru the rear hole of the bracket, washer and into the rear hole of the fender rail. **DO NOT TIGHTEN**
2. Repeat step 1 for the right side bracket.
3. Install the sissy bar between the brackets using the four supplied M8 x 20mm button head bolts
4. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
11/08

Anything's Possible.®

COBRA

® 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 2 - M10 x 40mm Button Head Bolts
- 2 - M10 x 50mm Button Head Bolts
- 4 - M8 x 20mm Button Head Bolts
- 4 - Washers

Application(s) >

Honda Aero 750 04-09, 2011-2014

Instruction Manual >

02-7618 / 02-8618

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar. Note: Install one side at a time

1. Remove the stock fender rail allen bolts from the fender rail. Install the left side sissy bar bracket with the stamped number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M10x50mm button head bolt thru the bracket, washer and into the fender rail. Insert the M10x40mm button head bolt thru the rear hole of the bracket, washer and into the rear hole of the fender rail. **DO NOT TIGHTEN**
2. Repeat step 1 for the right side bracket.
3. Install the sissy bar between the brackets using the four supplied M8 x 20mm button head bolts
4. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
11/08

Anything's Possible.®