

# COBRA

© 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

## Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - 8mm x 20mm Button head Bolts
- 4 - 8mm x 40mm Button head Bolts

## Application(s) >

Yamaha V-Star 650 Classic 98-10

## Instruction Manual >

02-7701 / 02-8701

**Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.**

1. Remove the two (2) rear bolts on each fender rail, first on the right side.
2. Install the brackets with the bent portion toward the inside (part number) using supplied 8mm x 40mm bolts and tighten. Brackets will mount on the outside of fender rail. Repeat on the left side.
1. Install the sissy bar to the brackets using the supplied 8mm x 20mm bolts and tighten. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019REV. A  
11/08

**Anything's Possible.®**

# COBRA

© 23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

## Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - 8mm x 20mm Button head Bolts
- 4 - 8mm x 40mm Button head Bolts

## Application(s) >

Yamaha V-Star 650 Classic 98-10

## Instruction Manual >

02-7701 / 02-8701

**Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.**

1. Remove the two (2) rear bolts on each fender rail, first on the right side.
2. Install the brackets with the bent portion toward the inside (part number) using supplied 8mm x 40mm bolts and tighten. Brackets will mount on the outside of fender rail. Repeat on the left side.
2. Install the sissy bar to the brackets using the supplied 8mm x 20mm bolts and tighten. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019REV. A  
11/08

**Anything's Possible.®**