

## Items Supplied >

- 1 – 18" Wire with Push On Connector
- 1 – Push On Connector
- 1 – Blue Quick Splice Connector
- 1 – Light bar Assembly W/Turn Signals

## Application(s) >

HONDA ACE 750 DELUXE 98-03

## Instruction Manual >

04-0115

Page 1 of 1

**Read all instructions carefully and completely before installing your new light bar. It is recommended that a qualified mechanic or technician install this product.**

1. Your Boulevard light bar comes with everything you need to mount it to your motorcycle. After unpacking the light bar, you will need to turn the spot lights around 180 degrees. They are facing backwards for packaging purposes only.
2. Remove your headlight from the headlight housing by removing the 2 Phillips screws. Follow the leads from your turn indicators into the head light housing and unplug them noting the wire colors for later assembly.
3. Remove the complete turn signal bar assembly from the front of motorcycle. Remove the 4 bolts on the top of the lower triple clamp that secure the chrome fork covers and save, your light bar will install in this location.
4. Align the light bar assembly and tighten the 4 previously removed bolts and tighten to factory torque specifications. Check to make sure that the screws on top of the light bar frame that hold the turn indicators to the light bar are snug.
5. Twist the ends of the 2 spotlight wires together and insert them into the supplied push on connector and crimp with wire crimp tool. Connect this to one pole on your light bar switch, it doesn't matter which one. Feed the wire from the light bar switch through the back of the headlight housing. Attach the wire from the switch to the blue/white wire (headlight dimmer power) located in the main wire loom inside your headlight housing.
6. Plug your new turn signal wires into the locations that your original ones were in the headlight housing using the chart below. Reinstall the headlight bulb assembly back into its housing with the two Phillips screws.
7. **Check to make sure that your handlebars turn lock to lock without any stretching or binding of any wires.** Check the alignment of all your lighting; make sure everything is working properly before riding.

### WIRING CHART

| Application          | Motorcycle     | Light Bar    |
|----------------------|----------------|--------------|
| Ground               | Green          | Black/Yellow |
| Turn Indicator Left  | Orange         | Blue         |
| Running Light Left   | Orange/White   | Gray         |
| Turn Indicator Right | Lt. Blue       | Blue         |
| Running Light Right  | Lt. Blue/White | Gray         |

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*