

Items Supplied >

- 1 – Radiator Cover
- 1 – Bolt, M6 x 30 mm B.H.C.S.
- 2 – Double Sided Adhesive Tape

Application(s) >

HONDA, AERO 750

04-09, 11-14

Instruction Manual >

05-9346

Page 1 of 1

Read all instructions carefully before installing your new Cobra product!

1. Remove the M6 bolt from the top of the radiator plastic cover and discard, do not remove the steel collar or plastic cover.
2. Clean the stock plastic radiator cover with glass cleaner along the lower section, where the double-sided tape from the new chrome cover will adhere.
3. Peel off the backing from the double-sided tape on the new chrome cover. Place the chrome radiator cover over the stock plastic cover. Install the supplied M6 x 30 mm Button head screw through the chrome and plastic covers and into the frame and tighten to factory specifications. Hold pressure on the chrome cover where the tape is located at least one minute until it secures itself. **Do not pull on the chrome cover to check how well it is stuck.** The high bond adhesive reaches full strength in 72 hours. Wait at least 24 hours before riding your motorcycle.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*