

## Items Supplied >

1 – LEFT PLATED MUFFLER ASSEMBLY  
1 – RIGHT PLATED MUFFLER ASSEMBLY  
2 – CLAMP, 27-61 MSC

## Application(s) >

HARLEY:  
ALL DRESSER MODELS 95-16

## Instruction Manual >

6201SD/UC & 6202

Page 1 of 1

**Read all instructions carefully and completely before installing your new exhaust system.**

1. Remove the saddle bags carefully.
2. Loosen the stock muffler clamps and remove the stock muffler bolts and save, these will be reused for installation of the new mufflers. Slide the stock mufflers off the headpipes.
3. Place the supplied Cobra clamps on each new muffler, then slide onto stock headpipes, make sure the stock heatshields cover the front weld of the Cobra mufflers. Using stock mounting bolts secure new mufflers to the bike (Cobra logo should be facing out) **do not tighten clamps & bolts completely yet.** Note: Make sure clamps are on the slotted portions of the muffler slip connector only. If they are too far back they will not tighten properly.
4. Make sure the mufflers are even on the rear of the bike, and then tighten bolts followed by the clamps.
5. Replace bags carefully.

**Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration.**

**\* Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**