

Items Supplied >

- 1 - Freeway Bar
- 2 - 8mm Flat Washers
- 2 - 8mm x 35mm Hex Bolts
- 4 - 5-1/16" x 3/4" SS Button Head Bolts
- 2 - Aluminum Clamps

Application >

ACE 750 98-03

Instruction Manual >

01-1115

Page 1 of 1

1. Remove the front bolt from each footpeg mounting bracket at the frame. To ease removal of the right footpeg mounting bolt loosen the hardware used to mount the front head pipe so it can be moved (not removed) to allow clearance to the bolt.
2. Remove the top bolt from the radiator to loosen the radiator cover so the top of the cover can be moved forward.
3. Install the freeway bar using the supplied 8mm x 35mm hex bolts and washers so that both long brackets mount where you removed the bolts in step #1.
4. Mount the top of the freeway bar to the frame tubes using the supplied u-shaped aluminum frame clamps and button head bolts.
5. Tighten all the hardware loosened in step 1.
6. Reinstall the bolt removed in step 2.
7. Torque all installed bolts and screws to appropriate values.

Cobra Freeway Bars add style to your motorcycle. They are not designed to withstand a serious impact and may not protect you and/or your motorcycle in the event of a crash.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*