



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - 8mm x 65mm Button Head Bolts
- 4 - 8mm x 16mm Button Head Bolts
- 2 - Thick Spacers (.170)
- 2 - Thin Spacers (.095)

Application(s) >

MAGNA 750 94-03

Instruction Manual >

02-4610/02-5110/02-5610

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the four (4) bolts on each fender rail.
2. Install each sissy bar bracket with the bend to the inside (part number) using the supplied 8mm x 65mm bolts. Install the thicker (.170) spacer on the front bolt between the bracket and the fender rail. Install the thinner (.095) spacer on the rear bolt between the bracket and the fender rail.
3. Attach the sissy bar to the brackets using the supplied 8mm x 16mm bolts.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A
10/03

Anything's Possible.



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - 8mm x 65mm Button Head Bolts
- 4 - 8mm x 16mm Button Head Bolts
- 2 - Thick Spacers (.170)
- 2 - Thin Spacers (.095)

Application(s) >

MAGNA 750 94-03

Instruction Manual >

02-4610/02-5110/02-5610

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the four (4) bolts on each fender rail.
2. Install each sissy bar bracket with the bend to the inside (part number) using the supplied 8mm x 65mm bolts. Install the thicker (.170) spacer on the front bolt between the bracket and the fender rail. Install the thinner (.095) spacer on the rear bolt between the bracket and the fender rail.
3. Attach the sissy bar to the brackets using the supplied 8mm x 16mm bolts.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A
10/03

Anything's Possible.