



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

[www.cobrausa.com](http://www.cobrausa.com)

### Items Supplied >

- 1 - Left Saddlebag Support
- 1 - Right Saddlebag Support
- 2 – M8 x 16mm Buttonhead Screws
- 2 – M8 x 35 mm Buttonhead Screws

### Application(s) >

Honda Rebel 250 1996 - 2015

### Instruction Manual >

02-6105

**Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.**

1. Remove the (2) left M8 fender rail bolts / nuts, but save the M8 nut to be used in the next step.
2. Install left saddlebag support with the upper bend to the front and inserting the longer M8 X 35 mm screw through the front mount hole, fender rail / frame and into the stock M8 nut retained from Step 1. Insert the shorter M8 X 16mm screw into the rear-mounting hole and into frame. Align and tighten screws to factory specifications.
3. Repeat Steps 1 and 2 on the right side of the Motorcycle.

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

[www.cobrausa.com](http://www.cobrausa.com)

### Items Supplied >

- 1 - Left Saddlebag Support
- 1 - Right Saddlebag Support
- 2 – M8 x 16mm Buttonhead Screws
- 2 – M8 x 35 mm Buttonhead Screws

### Application(s) >

Honda Rebel 250 1996 - 2015

### Instruction Manual >

02-6105

**Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.**

1. Remove the (2) left M8 fender rail bolts / nuts, but save the M8 nut to be used in the next step.
2. Install left saddlebag support with the upper bend to the front and inserting the longer M8 X 35 mm screw through the front mount hole, fender rail / frame and into the stock M8 nut retained from Step 1. Insert the shorter M8 X 16mm screw into the rear mounting hole and into frame. Align and tighten screws to factory specifications.
3. Repeat Steps 1 and 2 on the right side of the Motorcycle.

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A  
12/08

***Anything's Possible.®***