

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

Items Supplied >

- 1 – LEFT SADDLEBAG SUPPORT
- 1 – RIGHT SADDLEBAG SUPPORT
- 2 – BOLT, M8 X 40mm BUTTONHEAD
- 2 – BOLT, M8 X 50mm BUTTONHEAD
- 4 – WASHER, 5/16" FLAT

Application(s) >

www.cobrausa.com

YAMAHA STRYKER

2011-2018

Instruction Manual >

02-6270

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

1. Remove your stock fender rail bolts on left side and discard.
2. Place a supplied washer between each saddlebag support bushing and the fender rail, then insert the longer supplied M8 x 50mm bolt thru the front and the shorter M8 x 40mm bolt thru the rear. **NOTE:** The upper bend of the saddlebag support should point towards the front.
3. Repeat Steps 1 & 2 on the right side of the motorcycle.
4. Torque bolts to factory specifications.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
06/11

Anything's Possible.®

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 – LEFT SADDLEBAG SUPPORT
- 1 – RIGHT SADDLEBAG SUPPORT
- 2 – BOLT, M8 X 40mm BUTTONHEAD
- 2 – BOLT, M8 X 50mm BUTTONHEAD
- 4 – WASHER, 5/16" FLAT

Application(s) >

YAMAHA STRYKER 2011-2018

Instruction Manual >

02-6270

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

1. Remove your stock fender rail bolts on left side and discard.
2. Place a supplied washer between each saddlebag support bushing and the fender rail, then insert the longer supplied M8 x 50mm bolt in the front and the shorter M8 x 40mm bolt in the rear. **NOTE:** The upper bend of the saddlebag support should point towards the front.
3. Repeat Steps 1 & 2 on the right side of the motorcycle.
4. Torque bolts to factory specifications.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
06/11

Anything's Possible.®