

## Items Supplied >

- 1 - Front Exhaust
- 1 - Rear Exhaust
- 1 - Black Pipe Mount Bracket
- 3 - 5/16" Hex Nuts
- 3 - 5/16" Flat Washers
- 3 - 5/16" Lock Washers
- 2 - 5/16" x 1 1/4" Hex Bolts
- 1 - 5/16" x 3/4" Hex Bolt
- 2 - 2" Heat Shields

## Application >

HONDA ACE 750 98-03

## Instruction Manual >

1271

Page 1 of 1

**PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.**

1. Remove your stock exhaust system and large exhaust bracket from the motorcycle frame.
2. Mount the supplied black bracket on the outside of the motorcycle frame in place of the original large exhaust bracket using the supplied hardware. Note: The single oval hole in the new bracket should be pointing up and back.
3. Install the front exhaust pipe to the front cylinder head using the stock hardware. Bolt the bracket on the pipe to the lower frame mount of the new black bracket using the supplied hardware.
4. Install the rear exhaust pipe to the rear cylinder head using the stock hardware. Bolt the bracket on the pipe to the forward hole in the new black bracket using the supplied hardware.

**IMPORTANT:** It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-1271.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*