

## Items Supplied >

- 1 - Front Muffler
- 1 - Rear Muffler
- 1 - Front Heat Shield w/clamp
- 1 - Rear Heat Shield w/clamps
- 1 - 8mm x 30mm Hex Bolt
- 1 - 5/16" x 3/4" Hex Bolt
- 2 - 5/16" Lock Washers
- 2 - #268-55 T-Bolt Clamps
- 3 - #24 Hose Clamps

## Application >

SUZUKI MARAUDER 800 99-04

## Instruction Manual >

3162SC/3262

Page 1 of 1

**PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.**

1. Remove the stock mufflers. To do this, loosen and pull the right front head pipe out of the exhaust port. Then, slide the exhaust muffler out of the mounting holes and off of the motorcycle.
2. Install the rear muffler with the mounting bracket on the inside and below the stock frame bracket using the supplied 8mm x 30mm hex bolt and lock washer.
3. Install the front muffler to the bracket on the lower Cobra Muffler using the supplied 5/16 x 3/4 hex bolt and lock washer.
4. Install the heat shields using the supplied hose clamps.

**IMPORTANT:** It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-3164.

**Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.**

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*