



Items Supplied >

- 1 - Sissy Bar w/ Pad
- 2 - Mount Brackets (Left/Right)
- 2 - 3/8"-16 x 1 1/4" Buttonhead Bolts
- 4 - M8 x 16mm Buttonhead Bolts

Application(s) >

HARLEY DYNA 2006 - 2017

Instruction Manual >

602-1102 / 602-1152 / 602-1202

Page 1 of 2

Read all instructions carefully before installing your new Cobra® product!

1. If the motorcycle is equipped with rear reflectors than they must be removed along with any remaining adhesive left on the motorcycle. Save the reflectors for reuse.
2. Remove the front bolt from the right side fender rail and discard. **NOTE:** Remove only one side of fender bolts at a time otherwise fender may fall - resulting in possible scratches or damage to fender/paint.
3. Remove the rear turnsignal 5/16" bolt and star washer from the inside of the fender. Save the star washer and bolt for later reuse. **NOTE:** Extra clearance may be needed between rear tire and fender to remove bolt from turnsignal.
4. Remove the fender nutplate from the inside of the fender. See Figure 1.
5. Install right sissy bar mounting bracket between the fender rail and fender (part # facing inward). **NOTE:** Be careful not to scratch the fender paint when positioning the sissy bar mounting bracket. Make sure turnsignal wiring passes through the cutout (slot). Align the front and rear holes in the sissy bar bracket with the fender rail/chrome cover and replace the fender nutplate. See Figure 1.
6. Insert a supplied 3/8"-16 x 1 1/4" buttonhead bolt through the front hole of the chrome cover/fender rail, sissy bar mount bracket, and fender; thread the bolt into the stock fender nutplate. **DO NOT TIGHTEN AT THIS TIME.**
7. From the inside, insert the stock 5/16" bolt (with stock star washer) through the rear hole of the nutplate, fender, sissy bar mount bracket, and chrome cover/fender rail; thread the bolt into the turnsignal. **DO NOT TIGHTEN AT THIS TIME.**
8. Repeat Steps 2-6 on left side.
9. Install the sissy bar between the brackets using the four (4) supplied M8 x 16mm buttonhead bolts.
10. Align sissy bar and torque all bolts to their appropriate values. Attach the rear reflectors onto the chrome covers.

DECORATIVE BACKREST INSERTS AVAILABLE AT COBRAUSA.COM OR YOUR LOCAL COBRA DEALER

*** Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**

