



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

2 – Floorboard Assemblies

Application(s) >

KAWASAKI VN1600A 03
KAWASAKI VN2000

Instruction Manual >

06-1961

Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.

1. Remove your original floorboard from its mount on one side saving the pins, clips and spring. Install the Cobra floorboard to the original mount using the stock hardware.
2. Repeat step #2 on the other side.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A
04/03

Anything's Possible.



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

2 – Floorboard Assemblies

Application(s) >

KAWASAKI VN1600A 03
KAWASAKI VN2000

Instruction Manual >

06-1961

Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.

1. Remove your original floorboard from its mount on one side saving the pins, clips and spring. Install the Cobra floorboard to the original mount using the stock hardware.
2. Repeat step #2 on the other side.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A
04/03

Anything's Possible.