



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

**Items Supplied >**

- 2 - Floorboards
- 4 - 5/16" Flat Washers

**Application(s) >**

- YAMAHA ROYAL STAR 96-01
- YAMAHA ROADSTAR 1600/1700 99-UP
- YAMAHA V-STAR 1100 CLASSIC 99-UP

**Instruction Manual >**

06-4250

Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.

**NOTE:** Please notice the way the stock spring is installed on the stock floorboards. The Cobra floorboards will need to be installed in the same way.

1. Remove your stock floorboard from its mount on one side saving the pin, clip and spring. Install the Cobra floorboard to the original mount by placing two (2) of the supplied washers between the stock mount and the Cobra floorboard. Re-install the saved hardware.
2. Repeat step #1 on the other side.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
04/01

**Anything's Possible.**



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

**Items Supplied >**

- 2 - Floorboards
- 4 - 5/16" Flat Washers

**Application(s) >**

- YAMAHA ROYAL STAR 96-01
- YAMAHA ROADSTAR 1600/1700 99-UP
- YAMAHA V-STAR 1100 CLASSIC 99-UP

**Instruction Manual >**

06-4250

Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.

**NOTE:** Please notice the way the stock spring is installed on the stock floorboards. The Cobra floorboards will need to be installed in the same way.

1. Remove your stock floorboard from its mount on one side saving the pin, clip and spring. Install the Cobra floorboard to the original mount by placing two (2) of the supplied washers between the stock mount and the Cobra floorboard. Re-install the saved hardware.
2. Repeat step #1 on the other side.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
04/01

**Anything's Possible.**