

## Items Supplied >

2 – Floorboard Assemblies

## Application(s) >

KAWASAKI VN1600A 03-UP  
KAWASAKI VN1600D NOMAD 05-UP  
KAWASAKI VN2000 04-UP

## Instruction Manual >

06-4461

**Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.**

1. Identify the left & the right floorboard and place along appropriate side of vehicle.
2. Remove your original floorboard from its mount on one side saving the pins, clips and spring. Install the Cobra floorboard to the original mount using the stock hardware.
3. Repeat step #2 on the other side

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
03/03

**Anything's Possible.**

## Items Supplied >

2 – Floorboard Assemblies

## Application(s) >

KAWASAKI VN1600A 03-UP  
KAWASAKI VN1600D NOMAD 05-UP  
KAWASAKI VN2000 04-UP

## Instruction Manual >

06-4461

**Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.**

1. Identify the left & the right floorboard and place along appropriate side of vehicle.
2. Remove your original floorboard from its mount on one side saving the pins, clips and spring. Install the Cobra floorboard to the original mount using the stock hardware.
3. Repeat step #2 on the other side.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A  
03/03

**Anything's Possible.**