

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

Items Supplied >

2 - Floorboard Assemblies with Mounts

Application(s) >

www.cobrausa.com

YAMAHA RAIDER

2008-2014

Instruction Manual >

06-4765

Read all instructions carefully and completely before installing your new passenger floorboards.

1. Remove the 6mm bolt and nut holding the foot peg to the bike.
2. Remove the foot peg, detent shims, and ball.
3. Insert the new Floorboard Assembly into the motorcycle foot peg mount and install the 6mm bolt and nut.
(Torque to appropriate value)
4. Repeat on opposite side.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
11/08

Anything's Possible.®

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

2 - Floorboard Assemblies with Mounts

Application(s) >

YAMAHA RAIDER

2008-2014

Instruction Manual >

06-4765

Read all instructions carefully and completely before installing your new passenger floorboards.

1. Remove the 6mm bolt and nut holding the foot peg to the bike.
2. Remove the foot peg, detent shims, and ball.
3. Insert the new Floorboard Assembly into the motorcycle foot peg mount and install the 6mm bolt and nut.
(Torque to appropriate value)
4. Repeat on opposite side.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
11/08

Anything's Possible.®