



Items Supplied >

2 – Passenger Floorboard Assemblies

Application(s) >

Kawasaki VN1600D Nomad

Instruction Manual >

06-3942 / 06-4942

Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.

1. Remove the “E” clip from the end of the right passenger floorboard pin. Remove the pin, floorboard, spring and spring cap. Save all the hardware to use with the new floorboard. Locate your right side Cobra floorboard assembly and install it using the stock hardware in the original locations.
2. Repeat step #1 on the left side.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019REV. B

05/05



Items Supplied >

2 – Passenger Floorboard Assemblies

Application(s) >

Kawasaki VN1600D Nomad

Instruction Manual >

06-3942 / 06-4942

Your Floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Floorboards.

1. Remove the “E” clip from the end of the right passenger floorboard pin. Remove the pin, floorboard, spring and spring cap. Save all the hardware to use with the new floorboard. Locate your right side Cobra floorboard assembly and install it using the stock hardware in the original locations.
2. Repeat step #1 on the left side.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019REV. A

05/05