

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

Items Supplied >

- 1 Left Saddlebag Support
- 1 Right Saddlebag Support
- 4 M10 x 40 mm SS Buttonhead Bolts

Annl	ication	/al >	
Alololi	((07:111.0)))	151/	
		(·	

HONDA SPIRIT 750 C2 HONDA PHANTOM 750 07-09, 12-14

www.cobrausa.com

2010-2019

Instruction Manual >

02-6111

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

- 1. Remove your stock fender rail bolts.
- Install your Cobra saddlebag supports using the supplied M10 bolts. The saddlebags should hang towards the rear and away from the motorcycle.
- Torque bolts to factory specifications.

*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

Items Supplied >

- 1 Left Saddlebag Support
- 1 Right Saddlebag Support
- 4 M10 x 40 mm SS Buttonhead Bolts

Applicati	ion(s)	>
-----------	--------	---

HONDA SPIRIT 750 C2 HONDA PHANTOM 750 07-09, 12-14

www.cobrausa.com

2010-2019

Instruction Manual >

02-6111

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

- Remove your stock fender rail bolts.
- 2. Install your Cobra saddlebag supports using the supplied M10 bolts. The saddlebags should hang towards the rear and away from the motorcycle.
- 3. Torque bolts to factory specifications.

*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.