

Items Supplied >

- 1 Plated LH Saddlebag Support
- 1 Plated RH Saddlebag Support

Application(s) >

www.cobrausa.com

KAWASAKI VN1500P KAWASAKI VN1600A KAWASAKI VN1600B SUZUKI MARAUDER 1600

Instruction Manual >

- 02-6461
- 1. Remove the bolts from left side of rear fender but do not discard hardware.
- 2. Install the left side Cobra saddlebag rail using the stock hardware removed in step 1.
- 3. Repeat steps 1 thru 2 for right side of vehicle.
- 4. Check alignment of fender then torque fender bolts to factory specifications.
- * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

03/02

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016	
Items Sunnlied >	Application(s) >
1 – Plated LH Saddlebag Support 1 – Plated RH Saddlebag Support	KAWASAKI VN1500P KAWASAKI VN1600A KAWASAKI VN1600B SUZUKI MARAUDER 1600
Instruction Manual >	02-6461
1. Remove the bolts from left side of rear fender but do not discard hardware.	
2. Install the left side Cobra saddlebag rail using the stock hardware removed in step 1.	
3. Repeat steps 1 thru 2 for right side of vehicle.	
4. Check alignment of fender then torque fender bolts to factory specifications.	
* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.	

Anything's Possible.