

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

itellis Supplied >	
1 - Sissy Bar w/pad 2 - Brackets	
4 O OO D	in leased Dalks

2 - Brackets	
4 - 8mm x 20mm Button head Bolts	
4 - 8mm x 65mm Button head Bolts	
2 - Thick Spacers	

Application(s) >	www.cobrausa.com
Suzuki Volusia 800 Suzuki Boulevard M50 Suzuki Boulevard C50	01-04 05-14 05-14

Instruction Manual >

Itama Cumplied >

2 - Thin Spacers

02-7825 / 02-8825

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

- 1. Remove the two (2) rear bolts on each fender rail, first on the right side.
- 2. Install the brackets with the bent portion (part number) toward the inside using the supplied 8mm x 65mm bolts and spacers, brackets will mount on the outside of fender rail with the thick spacer in the rear & the thin spacer in the front. Repeat on left side.
- 3. Install the sissy bar to the brackets using the supplied 8mm x 20mm bolts and tighten. Tighten all mounting hardware to factory specifications.

*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

Items	Suppl	lied >
-------	-------	--------

- 1 Sissy Bar w/pad
- 2 Brackets
- 4 8mm x 20mm Button head Bolts
- 4 8mm x 65mm Button head Bolts
- 2 Thick Spacers
- 2 Thin Spacers

Application(s) >	www.cobrausa.com
Suzuki Volusia 800	01-04
Suzuki Boulevard M50	05-14
Suzuki Boulevard C50	05-14

Instruction Manual >

02-7825 / 02-8825

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

- 1. Remove the two (2) rear bolts on each fender rail, first on the right side.
- 2. Install the brackets with the bent portion (part number) toward the inside using the supplied 8mm x 65mm bolts and spacers, brackets will mount on the outside of fender rail with the thick spacer in the rear & the thin spacer in the front. Repeat on left side.
- 3. Install the sissy bar to the brackets using the supplied 8mm x 20mm bolts and tighten. Tighten all mounting hardware to factory specifications.

*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.