

Items Supplied >

- 1 – 20" Wire with Push On Connector
- 1 – Push On Connector
- 1 – Blue Quick Splice Connector
- 1 – Light bar Assembly W/Turn Signals

Application(s) >

HONDA AERO 98-02

Instruction Manual >

04-0122

Page 1 of 1

Read all instructions carefully and completely before installing your new lightbar. It is recommended that a qualified mechanic or technician install this product.

1. Your light bar comes with everything you need to mount it to your motorcycle. After unpacking the light bar, you will need to turn the spotlights around 180 degrees. They are facing backwards for packaging purposes only.
2. Remove your headlight from the headlight housing by removing the (2) Phillips screws. Follow the leads from your turn signal indicators into the headlight housing and unplug them noting the wire colors for later assembly.
3. Remove the complete turn signal bar assembly from the front of the motorcycle. Unbolt the headlight housing from the headlight-mounting bracket by removing the (3) bolts on the inside of the headlight housing.
4. Remove the (2) bolts from the headlight-mounting bracket. Place the light bar on top of the headlight-mounting bracket and mount with stock bolts. Re-install the headlight housing.
5. Twist the ends of the 2 spotlight wires together and insert them into the supplied push on connector and crimp with wire crimp tool. Connect this to one pole on your light bar switch, it doesn't matter which one. Feed the wire from the light bar switch through the back of the headlight housing. Attach the wire from the switch to the brown speedometer light wire located in the main wire loom inside your headlight housing.
6. Plug your new turn signal wires into the locations that your original ones were in the headlight housing using the chart below. Reinstall the headlight bulb assembly back into its housing with the two Phillips screws.
*** Note: Turn signal has connection harness attached, do not disconnect ***
7. **Check to make sure that your handlebars turn lock to lock without any stretching or binding of any wires.** Check the alignment of all your lighting, make sure everything is working properly before riding.

TURN SIGNAL WIRING CHART

Application	Motorcycle	Conn. Harness	Light Bar
Ground	Green	Black/Yellow	Black/Yellow
Turn Indicator Left	Orange	Blue	Blue
Running Light Left	Orange/White	Gray	Gray
Turn Indicator Right	Lt. Blue	Blue	Blue
Running Light Right	Lt. Blue/White	Gray	Gray
Main Power Source	Brown	N/A	Black (from switch)

*** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**