

Items Supplied >

- 1 – Light Bar Assembly
- 1 – 20" Wire with Push On Connector
- 1 – Spare Push On Connector
- 1 – Blue Quick Splice Connector
- 2 – 6mm x 12mm Button Head Bolts
- 4 – 4" Black Zip Ties

Application >

HONDA SABRE 00-07

Instruction Manual >

04-0135

Page 1 of 1

1. Remove the headlamp and turn signal bar.
2. Remove the turn signals from the bar.
3. Install the turn signals onto the Cobra light bar using the supplied 6mm x 12mm Button Head Bolts.
4. Remove the four (4) bolts holding the upper fork covers to the lower triple clamp.
5. Install the light bar on top of the lower triple clamp using the stock bolts removed in step 4.
6. Route the turn signal harnesses through the harness hole in your headlight housing and connect them to the motorcycle's turn signal harnesses.
7. Twist the ends of the two spot light wires together and insert them into the supplied push on connector and crimp with a wire crimp tool. Connect this wire to one pole on your light bar switch. It doesn't matter which one. Feed the wire from the light bar switch through the back of the headlight housing. Attach the wire from the switch to the brown & white speedometer light wire located in the speedometer wire loom inside your headlight housing using the supplied blue quick splice connector.
8. Check to make sure your handlebars turn lock to lock without any stretching or binding of any wires. Check the alignment of all of your lighting. Make sure everything is working properly before riding.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*