

Items Supplied >

1 – Swing Arm Cover

Application(s) >

VN1600A 03 and UP

Instruction Manual >

06-0963

Page 1 of 1

Before installing your Cobra swing arm cover read all instructions carefully

1. Remove the bolt attaching the muffler assembly to the right passenger foot peg bracket. Remove the two S.H.C. screws attaching the right passenger foot peg bracket to the motorcycle frame. Remove the right foot peg bracket.
2. Thoroughly clean the area with contact cleaner where the adhesive on the cover will make contact with the swing arm.
3. Peel the backing off of the two sided high bond adhesive strips and carefully place the cover into position on the swing arm. Make sure not to pinch the rear brake line when installing the swing arm cover.
4. Press firmly on the cover for one minute. **Do not pull on the cover to check how well it is stuck.** The high bond adhesive reaches full strength in 72 hours. Wait at least 24 hours before riding your motorcycle.
5. Reattach the hardware removed in step 1. Tighten all bolts to factory specifications.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*